

9\"
Ventiladordecorativo de 9 pulgadas
Modelo:VF-9DF
Modelo:VF-9DF

READ AND SAVE THESE INSTRUCTIONS
POR FAVOR LEA Y GUARDE ESTAS INSTRUCCIONES

Instruction Manual
Overview of Functions
Please read the following instructions carefully and retain a copy of this information for future reference. When using this or any electrical appliance, the following safety precautions should be strictly followed:
Safety & Warnings
1. WARNING: To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
2. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
3. Use the fan only for the specific purpose outlined in this instruction information.
4. Do not operate fan until fully assembled.
5. Ensure the correct voltage is being used prior to plugging in your fan (120V AC Electrical Outlet).
6. Unplug fan from outlet when not in use, when changing locations, before assembly or disassembly, or prior to cleaning.
7. Do not immerse fan or expose fan to any form of liquid.
8. Avoid contact with all moving parts. Never insert your fingers, pencils or other objects through the fan grill during operation.
9. Place your fan on a stable and level surface to avoid tipping or being knocked over accidentally.

10. Do not operate the fan directly adjacent to curtains, pla nts, window coverings, etc. to avoid accidental entanglement.
11. For indoor household use only. Do not use outdoors or for industrial or commercial purposes.
12. To avoid potential fire hazards, never place your fan or its electrical cord under rugs, or carpeting.
13. Place the electrical cord away from busy areas to avoid accidental tripping and contact.
14. Always insert or remove plug from the outlet by grabbing the plug by hand. Do not pull on the electrical cord.
15. Never operate your fan near an open flame or in the presence of explosive or combustible gases or fumes.
16. Should your fan (including the electrical cord) ever become damaged or a malfunction occurs, discontinue operation at once until a certified repair has been made.
17. Do not expose your fan to excessive heat or humidity, as this can cause damage to the electrical components.
18. Keep your fan out of the reach of children and pets.
19. Do not expose infants or seniors to prolonged periods of direct cold air.
Fan Assembly
1. Carefully unpack the assembled fan from the Styrofoam packing crate.
2. Make sure to remove all plastic covers and Styrofoam prior to using.
3. You are now ready to enjoy your fan!
Fan Use
1. The switch is located on at the back of the drum body
2. The fan has two speeds when turned on

Trouble Shooting

| PROBLEM | CORRECTIVE ACTION |
|--------------------------|---|
| The fan will not operate | Confirm that the fan switch is not in the OFF position Confirm the plug connectors are perfectly joined. |

Care & Cleaning
1. Be sure to unplug from the electrical supply source before cleaning.
2. Clean parts with a duster or damp cloth. Prior to resuming use, make sure all moisture is dry.
3. Do not immerse in any type of liquid or use abrasive cleaning solutions.
4. Use care around the motor housing as no excessive moisture or liquid should come in contact with the motor housing or its parts.
5. When storing your fan make sure to place in a dry environment. To reduce dust and particle exposure, it is best to cover your fan –especially in the off-season period.

USER SERVICING INSTRUCTIONS
NOTE:This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user serving instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

HOW TO REPLACE THE FUSE
• Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover by sliding it toward blades (see Fig. 5). Then remove the fuse, pry it out carefully (see Fig. 6). Replace the new fuse and push the cover back.
• **WARNING:** Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Do not replace attachment plug. Discard product if the attachment plug is damaged.

PRODUCT WARRANTY
Product carries a one year (1 year) limited warranty. The warranty warrants that the product will be free of defects of material(s) and workmanship for the period of one year from the date of purchase. A dated receipt reflecting the date of purchase must be presented when making a warranty claim.

Made in China

Manuel d'Instructions
Aperçu des Fonctions
Veuillez lire attentivement les instructions suivantes et conserver une copie de ces instructions pour des références ultérieures. Lors de l'utilisation de cet appareil ou de tout autre appareil électrique, les précautions de sécurité suivantes doivent être suivies à la lettre:
Sécurité & Avertissements
1. N'utilisez ce ventilateur que pour l'usage spécifique expliqué dans ces informations d'instruction.
2. Ne pas mettre le ventilateur en marche jusqu'à ce qu'il soit totalement assemblé.
3. Assurez-vous que le voltage convenable est utilisé avant de brancher votre ventilateur (Prise de courant 120V AC).
4. Débranchez le ventilateur de la prise de courant quand vous ne l'utilisez pas, quand vous changez son emplacement, avant l'assemblage ou le démontage, ou avant le nettoyage.
5. Ne pas immerger le ventilateur ou l'exposer à n'importe quelle sorte de liquide.
6. Évitez le contact avec toute pièce mobile. Ne jamais insérer vos doigts, crayons ou autres objets à travers la grille du ventilateur s'il est en marche.
7. Placez votre ventilateur sur une surface stable et horizontale pour éviter de le faire basculer ou de le faire tomber accidentellement.
8. Ne pas mettre le ventilateur en marche directement près des rideaux, plantes, décors de fenêtres, etc. pour éviter tout accrochage accidentel.
9. Uniquement conçu pour un usage interne. Ne pas utiliser à l'extérieur ou pour des usages industriels ou commerciaux.

Utilisation du Ventilateur
1. Le commutateur dessus localisé de tambour.
2. Le ventilateur a deux vitesses quand a allumé.
DÉP ANNAGE

| PROBLEME | MESURE CORRECTIVE |
|-----------------------------------|---|
| Le ventilateur ne fonctionne pas. | Assurez-vous que l'interrupteur n'est pas sur la position d'arrêt (OFF). Vérifiez que la fiche est bien branchée sur la prise. |

Entretien & Nettoyage
1. Toujours mettre votre ventilateur sur la position off avant de le nettoyer.
2. Nettoyer les pièces avec un chiffon à poussière ou un torchon humide. Avant de remettre en marche, assurez-vous que c'est totalement sec.
3. Ne pas immerger le ventilateur dans n'importe quelle sorte de liquide ou utiliser des détergents abrasifs.
4. Soyez prudent autour du boîtier du moteur et ses pièces et ne pas les exposer à une humidité excessive ou un liquide quelconque.
5. Quand vous entreposez votre ventilateur, assurez-vous que l'endroit est sec. Pour réduire son exposition à la poussière et aux particules, il est préférable de couvrir votre ventilateur– surtout hors-saison.

Hecho en China

0 42630 70745 4

9\"
Ventiladordecorativo de 9 pulgadas
Modelo:VF-9DF
Modelo:VF-9DF

READ AND SAVE THESE INSTRUCTIONS
POR FAVOR LEA Y GUARDE ESTAS INSTRUCCIONES

Instruction Manual
Overview of Functions
Please read the following instructions carefully and retain a copy of this information for future reference. When using this or any electrical appliance, the following safety precautions should be strictly followed:
Safety & Warnings
1. WARNING: To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
2. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
3. Use the fan only for the specific purpose outlined in this instruction information.
4. Do not operate fan until fully assembled.
5. Ensure the correct voltage is being used prior to plugging in your fan (120V AC Electrical Outlet).
6. Unplug fan from outlet when not in use, when changing locations, before assembly or disassembly, or prior to cleaning.
7. Do not immerse fan or expose fan to any form of liquid.
8. Avoid contact with all moving parts. Never insert your fingers, pencils or other objects through the fan grill during operation.
9. Place your fan on a stable and level surface to avoid tipping or being knocked over accidentally.

10. Do not operate the fan directly adjacent to curtains, pla nts, window coverings, etc. to avoid accidental entanglement.
11. For indoor household use only. Do not use outdoors or for industrial or commercial purposes.
12. To avoid potential fire hazards, never place your fan or its electrical cord under rugs, or carpeting.
13. Place the electrical cord away from busy areas to avoid accidental tripping and contact.
14. Always insert or remove plug from the outlet by grabbing the plug by hand. Do not pull on the electrical cord.
15. Never operate your fan near an open flame or in the presence of explosive or combustible gases or fumes.
16. Should your fan (including the electrical cord) ever become damaged or a malfunction occurs, discontinue operation at once until a certified repair has been made.
17. Do not expose your fan to excessive heat or humidity, as this can cause damage to the electrical components.
18. Keep your fan out of the reach of children and pets.
19. Do not expose infants or seniors to prolonged periods of direct cold air.
Fan Assembly
1. Carefully unpack the assembled fan from the Styrofoam packing crate.
2. Make sure to remove all plastic covers and Styrofoam prior to using.
3. You are now ready to enjoy your fan!
Fan Use
1. The switch is located on at the back of the drum body
2. The fan has two speeds when turned on

Trouble Shooting

| PROBLEM | CORRECTIVE ACTION |
|--------------------------|---|
| The fan will not operate | Confirm that the fan switch is not in the OFF position Confirm the plug connectors are perfectly joined. |

Care & Cleaning
1. Be sure to unplug from the electrical supply source before cleaning.
2. Clean parts with a duster or damp cloth. Prior to resuming use, make sure all moisture is dry.
3. Do not immerse in any type of liquid or use abrasive cleaning solutions.
4. Use care around the motor housing as no excessive moisture or liquid should come in contact with the motor housing or its parts.
5. When storing your fan make sure to place in a dry environment. To reduce dust and particle exposure, it is best to cover your fan –especially in the off-season period.

USER SERVICING INSTRUCTIONS
NOTE:This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user serving instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

HOW TO REPLACE THE FUSE
• Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover by sliding it toward blades (see Fig. 5). Then remove the fuse, pry it out carefully (see Fig. 6). Replace the new fuse and push the cover back.
• **WARNING:** Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Do not replace attachment plug. Discard product if the attachment plug is damaged.

PRODUCT WARRANTY
Product carries a one year (1 year) limited warranty. The warranty warrants that the product will be free of defects of material(s) and workmanship for the period of one year from the date of purchase. A dated receipt reflecting the date of purchase must be presented when making a warranty claim.

Made in China

Manuel d'Instructions
Aperçu des Fonctions
Veuillez lire attentivement les instructions suivantes et conserver une copie de ces instructions pour des références ultérieures. Lors de l'utilisation de cet appareil ou de tout autre appareil électrique, les précautions de sécurité suivantes doivent être suivies à la lettre:
Sécurité & Avertissements
1. N'utilisez ce ventilateur que pour l'usage spécifique expliqué dans ces informations d'instruction.
2. Ne pas mettre le ventilateur en marche jusqu'à ce qu'il soit totalement assemblé.
3. Assurez-vous que le voltage convenable est utilisé avant de brancher votre ventilateur (Prise de courant 120V AC).
4. Débranchez le ventilateur de la prise de courant quand vous ne l'utilisez pas, quand vous changez son emplacement, avant l'assemblage ou le démontage, ou avant le nettoyage.
5. Ne pas immerger le ventilateur ou l'exposer à n'importe quelle sorte de liquide.
6. Évitez le contact avec toute pièce mobile. Ne jamais insérer vos doigts, crayons ou autres objets à travers la grille du ventilateur s'il est en marche.
7. Placez votre ventilateur sur une surface stable et horizontale pour éviter de le faire basculer ou de le faire tomber accidentellement.
8. Ne pas mettre le ventilateur en marche directement près des rideaux, plantes, décors de fenêtres, etc. pour éviter tout accrochage accidentel.
9. Uniquement conçu pour un usage interne. Ne pas utiliser à l'extérieur ou pour des usages industriels ou commerciaux.

Utilisation du Ventilateur
1. Le commutateur dessus localisé de tambour.
2. Le ventilateur a deux vitesses quand a allumé.
DÉP ANNAGE

| PROBLEME | MESURE CORRECTIVE |
|-----------------------------------|---|
| Le ventilateur ne fonctionne pas. | Assurez-vous que l'interrupteur n'est pas sur la position d'arrêt (OFF). Vérifiez que la fiche est bien branchée sur la prise. |

Entretien & Nettoyage
1. Toujours mettre votre ventilateur sur la position off avant de le nettoyer.
2. Nettoyer les pièces avec un chiffon à poussière ou un torchon humide. Avant de remettre en marche, assurez-vous que c'est totalement sec.
3. Ne pas immerger le ventilateur dans n'importe quelle sorte de liquide ou utiliser des détergents abrasifs.
4. Soyez prudent autour du boîtier du moteur et ses pièces et ne pas les exposer à une humidité excessive ou un liquide quelconque.
5. Quand vous entreposez votre ventilateur, assurez-vous que l'endroit est sec. Pour réduire son exposition à la poussière et aux particules, il est préférable de couvrir votre ventilateur– surtout hors-saison.

Hecho en China

0 42630 70759 1

9\"
Ventiladordecorativo de 9 pulgadas
Modelo:VF-9DF
Modelo:VF-9DF

READ AND SAVE THESE INSTRUCTIONS
POR FAVOR LEA Y GUARDE ESTAS INSTRUCCIONES

Instruction Manual
Overview of Functions
Please read the following instructions carefully and retain a copy of this information for future reference. When using this or any electrical appliance, the following safety precautions should be strictly followed:
Safety & Warnings
1. WARNING: To reduce the risk of fire or electric shock, do not use this fan with any solid-state speed control device.
2. This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.
3. Use the fan only for the specific purpose outlined in this instruction information.
4. Do not operate fan until fully assembled.
5. Ensure the correct voltage is being used prior to plugging in your fan (120V AC Electrical Outlet).
6. Unplug fan from outlet when not in use, when changing locations, before assembly or disassembly, or prior to cleaning.
7. Do not immerse fan or expose fan to any form of liquid.
8. Avoid contact with all moving parts. Never insert your fingers, pencils or other objects through the fan grill during operation.
9. Place your fan on a stable and level surface to avoid tipping or being knocked over accidentally.

10. Do not operate the fan directly adjacent to curtains, pla nts, window coverings, etc. to avoid accidental entanglement.
11. For indoor household use only. Do not use outdoors or for industrial or commercial purposes.
12. To avoid potential fire hazards, never place your fan or its electrical cord under rugs, or carpeting.
13. Place the electrical cord away from busy areas to avoid accidental tripping and contact.
14. Always insert or remove plug from the outlet by grabbing the plug by hand. Do not pull on the electrical cord.
15. Never operate your fan near an open flame or in the presence of explosive or combustible gases or fumes.
16. Should your fan (including the electrical cord) ever become damaged or a malfunction occurs, discontinue operation at once until a certified repair has been made.
17. Do not expose your fan to excessive heat or humidity, as this can cause damage to the electrical components.
18. Keep your fan out of the reach of children and pets.
19. Do not expose infants or seniors to prolonged periods of direct cold air.
Fan Assembly
1. Carefully unpack the assembled fan from the Styrofoam packing crate.
2. Make sure to remove all plastic covers and Styrofoam prior to using.
3. You are now ready to enjoy your fan!
Fan Use
1. The switch is located on at the back of the drum body
2. The fan has two speeds when turned on

Trouble Shooting

| PROBLEM | CORRECTIVE ACTION |
|--------------------------|---|
| The fan will not operate | Confirm that the fan switch is not in the OFF position Confirm the plug connectors are perfectly joined. |

Care & Cleaning
1. Be sure to unplug from the electrical supply source before cleaning.
2. Clean parts with a duster or damp cloth. Prior to resuming use, make sure all moisture is dry.
3. Do not immerse in any type of liquid or use abrasive cleaning solutions.
4. Use care around the motor housing as no excessive moisture or liquid should come in contact with the motor housing or its parts.
5. When storing your fan make sure to place in a dry environment. To reduce dust and particle exposure, it is best to cover your fan –especially in the off-season period.

USER SERVICING INSTRUCTIONS
NOTE:This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user serving instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

HOW TO REPLACE THE FUSE
• Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord. Open fuse cover by sliding it toward blades (see Fig. 5). Then remove the fuse, pry it out carefully (see Fig. 6). Replace the new fuse and push the cover back.
• **WARNING:** Risk of fire. Replace fuse only with 5 Amp, 125 Volt fuse. Do not replace attachment plug. Discard product if the attachment plug is damaged.

PRODUCT WARRANTY
Product carries a one year (1 year) limited warranty. The warranty warrants that the product will be free of defects of material(s) and workmanship for the period of one year from the date of purchase. A dated receipt reflecting the date of purchase must be presented when making a warranty claim.

Made in China

Manuel d'Instructions
Aperçu des Fonctions
Veuillez lire attentivement les instructions suivantes et conserver une copie de ces instructions pour des références ultérieures. Lors de l'utilisation de cet appareil ou de tout autre appareil électrique, les précautions de sécurité suivantes doivent être suivies à la lettre:
Sécurité & Avertissements
1. N'utilisez ce ventilateur que pour l'usage spécifique expliqué dans ces informations d'instruction.
2. Ne pas mettre le ventilateur en marche jusqu'à ce qu'il soit totalement assemblé.
3. Assurez-vous que le voltage convenable est utilisé avant de brancher votre ventilateur (Prise de courant 120V AC).
4. Débranchez le ventilateur de la prise de courant quand vous ne l'utilisez pas, quand vous changez son emplacement, avant l'assemblage ou le démontage, ou avant le nettoyage.
5. Ne pas immerger le ventilateur ou l'exposer à n'importe quelle sorte de liquide.
6. Évitez le contact avec toute pièce mobile. Ne jamais insérer vos doigts, crayons ou autres objets à travers la grille du ventilateur s'il est en marche.
7. Placez votre ventilateur sur une surface stable et horizontale pour éviter de le faire basculer ou de le faire tomber accidentellement.
8. Ne pas mettre le ventilateur en marche directement près des rideaux, plantes, décors de fenêtres, etc. pour éviter tout accrochage accidentel.
9. Uniquement conçu pour un usage interne. Ne pas utiliser à l'extérieur ou pour des usages industriels ou commerciaux.

Utilisation du Ventilateur
1. Le commutateur dessus localisé de tambour.
2. Le ventilateur a deux vitesses quand a allumé.
DÉP ANNAGE

| PROBLEME | MESURE CORRECTIVE |
|-----------------------------------|---|
| Le ventilateur ne fonctionne pas. | Assurez-vous que l'interrupteur n'est pas sur la position d'arrêt (OFF). Vérifiez que la fiche est bien branchée sur la prise. |

Entretien & Nettoyage
1. Toujours mettre votre ventilateur sur la position off avant de le nettoyer.
2. Nettoyer les pièces avec un chiffon à poussière ou un torchon humide. Avant de remettre en marche, assurez-vous que c'est totalement sec.
3. Ne pas immerger le ventilateur dans n'importe quelle sorte de liquide ou utiliser des détergents abrasifs.
4. Soyez prudent autour du boîtier du moteur et ses pièces et ne pas les exposer à une humidité excessive ou un liquide quelconque.
5. Quand vous entreposez votre ventilateur, assurez-vous que l'endroit est sec. Pour réduire son exposition à la poussière et aux particules, il est préférable de couvrir votre ventilateur– surtout hors-saison.

Hecho en China

0 42630 70758 4